



M1934

EXPLODED VIEW



Parts

1.	Barrel	15.	Frame
2.	Slide	16.	Pin
3.	Hex Socket Head Cap Screws	17.	Slide Catch
4.	Firing Pin Kit	18.	Trigger Kit
5.	Spring	19.	Magazine Catch
6.	Recoil Axis	20.	Pin
7.	Barrel Housing	21.	Pin
8.	Catch Piece	22.	Magazine (Gas)
9.	Hammer Kit	23.	Magazine (CO2)
10.	Pin	24.	Left Grip
11.	Hammer Spring	25.	Grip Screw
12.	Hammer Housing	26.	Right Grip
13.	Hammer Plate	27.	CO2 Cylinder
14.	Plate Axis	28.	

