


EXPLODED VIEW


FS-0419

Parts

1.	Slide
2.	Barrel
3.	Frame
4.	Action housing
5.	Firing pin housing
6.	Grip safety
7.	Trigger
8.	Firing pin
9.	Trigger linkage toggle
10.	Toggle clip
11.	Firing pin catch
12.	Safety catch
13.	Magazine catch
14.	Grip guard
15.	Magazine
16.	Mag Follower
17.	extractor
18.	Grip spring piece
19.	Magazine spring
20.	Recoil spring
21.	Firing pin spring
22.	Safety catch spring
23.	Recoil bar
24.	Firing pin housing screw
25.	Locking axis
26.	Locking pin
27.	Locking pin
28.	Handguard screw
29.	Handguard screw
30.	Pin
33.	toggle



分解順序



清洗保養

