


EXPLODED VIEW

FS915

Parts



1.	Slide	36.	Hammer Plate Pin
2.	Extractor	37.	Hammer Base Pin
2-1.	Extractor Spring	38.	Trigger
3.	Extractor Spring	39.	Trigger Twist Spring
5.	Hammer Safety	40.	Trigger Pin
6.	Hammer Safety Pin	41.	Trigger Bar
7.	Hammer Safety Spring	42.	Trigger Bar Twist Spring
19.	Barrel	45.	Cartridge Ejection
23.	Recoil Bar	46.	Cartridge Ejection Pin
24.	Recoil Bar	47.	Slide Locking Bar
25.	Frame	48.	Locking Bar Button
26.	Action Housing	49.	Locking Bar Button Spring
29.	Hammer Housing	50.	Magazine Catch
30.	Hammer Axis	51.	Mag Catch Piston
31.	Hammer Bar Spring	52.	Mag Catch Spring
32.	Hammer Base	54.	Slide Catch
33.	Hammer Plate	55.	Slide Catch Twist Spring
34.	Hammer Plate Twist Spring	56.	Grip
35.	Hammer Housing Pin	57.	Grip Screw

