


FS22/FS27

EXPLODED VIEW



Parts

| | |
|-------|------------------------|
| 1. | Barrel |
| 2. | Frame |
| 3. | Grip |
| 4. | Firing Pin A |
| 5. | Firing Pin B |
| 6. | Trigger |
| 7. | Storage Cover |
| 8. | Barrel Latch |
| 9. | Frame Latch |
| 10. | Hollow Screw |
| 11. | Firing Pin Screw |
| 12. | Storage Cover Screw |
| 13. | Trigger Locking Pin |
| 13-1. | Frame Locking Pin |
| 14. | Firing Pin Locking Pin |
| 15. | Trigger Spring |
| 16. | Storage Cover Spring |
| 17. | Firing Pin Spring |
| | |
| C22 | .22 Bullet |
| C27 | .27 Bullet |

